

PANEL COMPONENTS & SYSTEMS, INCORPORATED



M850 Demand Reset Programming Guide

- 1. Press "I" & "E" simultaneously and hold for 5 seconds. The unit is now in setup mode. The screen will change to "SUPP"
- 2. Press "E" button until "df" is displayed (twice).
- 3. Press "I" until "rset" is displayed.
- 4. Press "I". Then press "Y" for Yes (rset).
- 5. Press "E" ("dt st" is displayed).
- 6. Press "E" until "CONF" is displayed. Then, press "I". Now the display shows "dt".
- 7. Press "E" until "END" is displayed. Then, press "I". Now you are out of programming mode.